

TEMPERATURE Centre Four "PERIGORD" 8733

Multiplier le thermostat par 30 et vous obtiendrez la température en degrés Celsius (Théoriquement)

Temps en minutes															
POSITION	<i>Données Théoriques</i>	0'	5'	10'	15'	20'	25'	30'	35'	40'	45'	50'	55'	60'	Moyenne après 15'
Debit réduit	<i>30</i>	20	98	127	145	156	168	173	177	178	181	182	182	182	172
Plein débit	<i>270</i>	19	170	219	245	263	275	279	284	287	288	290	292	292	280

